

AIRPORT DIAGRAM

AL-10 (FAA)

ALBANY INTL (ALB)
ALBANY, NEW YORK

ATIS 120.45
ALBANY TOWER
119.5 257.8
GND CON
121.7 348.6
CLNC DEL 127.50

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

42°45.5'N

42°45.0'N

42°44.5'N

42°44.0'N


73°48.5'W

73°48.0'W

73°47.5'W

NE-2, 03 JUL 2008 to 31 JUL 2008

NE-2, 03 JUL 2008 to 31 JUL 2008



AIRPORT DIAGRAM

ALBANY, NEW YORK
ALBANY INTL (ALB)