


AIRPORT DIAGRAM

SEATTLE/BOEING FIELD/KING COUNTY INTL (BFI)
AL-384 (FAA)
SEATTLE, WASHINGTON



ATIS 127.75
 BOEING TOWER
 120.6 257.8
 GND CON
 121.9
 CLNC DEL
 132.4

JANUARY 2005
 ANNUAL RATE OF CHANGE
 0.2°W
 VAR 17.8°E

NW-1, 03 JUL 2008 to 31 JUL 2008

NW-1, 03 JUL 2008 to 31 JUL 2008

RWY 13R-31L
 S100, D160, ST175, DT340
 RWY 13L-31R
 S35, D60
 Rwy 13R ldg 9120'
 Rwy 13L ldg 3470'
 Rwy 31L ldg 9120'
 Rwy 31R ldg 3345'

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

SEATTLE, WASHINGTON
SEATTLE/BOEING FIELD/KING COUNTY INTL (BFI)